

Network analyzers MAP



Measure up



UNIQUE SUPERVISION SOLUTION PRODUCTS - SOFTWARE

MAP range of fixed and portable network quality analyzers

Arbitration of electricity supply quality

- Class A according to the IEC 61000-4-30 standard
- Assessment of compliance with the EN50160 standard

Installation maintenance by recording 24/7

- V/U/I/P/Q/S electrical quantities and energy values
- Harmonics/Flicker/unbalance, etc.

Energy quality event diagnostics


- Detection of dips, outages, etc., and transients up to 2 MHz
- Associated RMS / cycle waveform

■ Simplified **management** of installed equipment


- Automatic, centralized backup of the recordings from each device
- Notification of the maintenance team in the event of anomalies

■ Benefit from a **global analysis** of the internal network or T&D network

- · Compare all the recorded electrical data to one another and between devices
- Analyze drift in relation to the templates (ITIC, UNIPEDE, Semi F47, etc.) affecting your crucial equipment
- Use the geographical location data and the possibilities of sorting by criteria offered by the analyzers to understand the origins of the various phenomena



Trend curves of the parameters recorded by the MAPs







Statistical view of events / ITI template



Analyzers

Power quality analyzers

Permanent analyzers - MAP range - Class A

MAP 607 Single-phase voltage quality analyzer



MAP 640 Three-phase voltage/current power quality analyzer with HF transient capture



MAP 610 Three-phase voltage quality analyzer



MAP Compact
Three-phase voltage/current
power quality analyzer
+ Energy - Monitoring of
EN50160 template



MAP 620 Three-phase voltage/current power quality analyzer



Non-intrusive analyzers - MAP range - Class A

MAP 612-NI Non-intrusive three-phase voltage quality analyzer with quick connection



MAP 620-NI Non-intrusive power analyzer - three-phase voltage/current





Management and analysis software

For MAP 607

Qual-SRT Configuration and real-time display software



Qual-View Analysis software for measurement campaigns



For MAP Compact

Qual-SRTc Configuration and real-time display software



Qual-View Analysis software for measurement campaigns



E.Qual-Premium Server
Management software for "medium
and large configurations".
Client/server software for configuration,
automatic data retrieval, multi-equipment
analysis, statistical display, report generation
and management of the measurements
in a database



For MAP 6XX range

E.Qual-Premium Management software for "small configurations". Point-to-point software for configuration, data retrieval, analysis and report generation



E.Qual-Premium Server
Management software for
"medium and large configurations".
Client/server software for configuration,
automatic data retrieval, multi-equipment
analysis, statistical display, report generation
and management of the measurements
in a database in a database







Choosing your power quality analyzer

► Based on its specifications

Permanent analyzers

Non-intrusive analyzers

			R.S.			31 31
	Single-phase			Three	e-phase	
	MAP 607	MAP 610	MAP 620	MAP 640	MAP 612-NI	MAP 620-NI
Installation						
Number of voltage channels	1	3	3	3	3	3
Number of HF voltage channels				3		
Number of current channels			4	4		4
Number of 0 — 20 mA inputs			4	4		
Sampling						
Sampling frequency	12.8 kHz	12.8 kHz	12.8 kHz	12.8 kHz	12.8 kHz	12.8 kHz
Frequency for fast transients				2 MHz		
Communication						
Mini USB	•					
CL port			•	•		
Internal Ethernet port		option	option	option	external	external
Local RS232 port		•	•	•	•	•
Remote RS232 port		•	•	•	•	•
Memory				·	•	
Capacity	64 MB	128 MB	128 MB	128 MB	128 MB	128 MB
Internal dock						
GPS synchronization via external coupler		•	•	•		
DCF synchronization via external coupler		•	•	•		
Back-up power supply and connections						
Internal power reserve	1 s	10 s	10 s	10 s	10 s	10 s
Power reserve via external UPS		10 mn	10 mn	10 mn	10 mn	10 mn
Voltage connections	Standardized plug	Screw-on	Screw-on	Screw-on	4 mm banana	4 mm banana
Current connections			Screw-on	Screw-on		1/4 turn (BNC type connection)
Strengths	Retrieval of measurements via USB 2.0 port - Plug & Play system.	Predefined reports as per EN50160. Possibility of programming a customized profile. Compliance with profile calculated in the product, thus minimizing the data to be transferred. Immediate indication of compliance with profile by LED on front panel. Possibility of managing the whole MAP600 range with the same software line.				



► Based on its functions

Permanent analyzers

Non-intrusive analyzers

	Single-phase			Three	-Phase		
	MAP 607	MAP 610	MAP 620	MAP 640	MAP 612-NI	MAP 620-NI	
Parameters calculated							
Voltage	•	•	•	•	•	•	
Frequency	•	•	•	•	•	•	
Unbalance	•	•	•	•	•	•	
THD	•	•	•	•	•	•	
Harmonics (up to 50th order)	•	•	•	•	•	•	
Flicker: Pst (10 min), Plt (2 h) and Lfl (inst.)	•	•	•	•	•	•	
Signalling voltages	•	•	•	•	•	•	
Power harmonics			•	•		•	
P, Q and S power values			•	•		•	
Power factors, tangents			•	•		•	
Voltage events						<u> </u>	
Dips	•	•	•	•	•	•	
Interruption / outage	•	•	•	•	•	•	
Transients	•	•	•	•	•	•	
Fast variations	•	•	•	•	•	•	
Event log	•	•	•	•	•	•	
HF transients				•			
Event capture and recording							
Signature	•	•	•	•	•	•	
Waveforms	•	•	•	•	•	•	
Customizable power quality reports	•	•	•	•	•	•	
Connexion							
Quick / non-intrusive connection	•				•	•	
IP65 connection		·					
Software							
Qual SRT / Qual-View	•						
E.Qual-Premium		•	•	•	•	•	
E.Qual-Premium-Server	• (import)	•	•	•	•	•	






Info & advice

Power supply faults and deteriorating electrical power quality cause disturbances which adversely affect the operation of electro-technical equipment. What are the disturbances involved? What are their causes and consequences?

SLOW VARIATIONS AND INTERRUPTIONS

The amplitude of the voltage is usually the primary contractual commitment given by the power distributor. It is nevertheless subject to abnormal variations which may reach a level close to 0.



The nominal range of variation of the network voltage is set by the power distributor at ± 10% of the phase-to-phase voltage.

Faults generated


Causes linked to disturbances due to equipments

Causes linked to electrical power supply networks Parameters to be measured

- Voltage surge or dip
- ► Micro-interruptions < 10 ms
- ► Short interruptions < 3 min and long interruptions > 3 min
- ► Heavy loads connected to a network whose short-circuit power at a delivery point is undersized
- ► High-power motors, transformers and capacitor banks
- Internal faults in the electrical installation
- Atmospheric phenomena and accidental short-circuits
- ► Transmission and distribution network management problems
- Amplitude and duration of the variation

RAPID VARIATIONS

Digital analyzers with a high sampling frequency are necessary to measure transient overvoltages.



Causes linked to disturbances due to equipment

Faults generated

Causes linked to electrical power supply networks

Parameters to be measured

- ► Transient overvoltages (<10 ms)
- ► Switching of more or less inductive loads causing transient overvoltages at high frequency
- ▶ Switching of 2 thyristors causing a very brief short-circuit between the 2 phases
- Atmospheric phenomena (lightning)
- Maximum amplitude and duration of the transient

RAPID VOLTAGE VARIATIONS (FLICKER)

The discomfort caused by rapid variations in the brightness of lighting is measured by the flicker value. Effects on people: headache, irritability, epileptic fit, etc.



Faults generated Causes linked

to equipment

to disturbances due


Causes linked to electrical

Parameters to be measured

► Variation of brightness

- Flickering of computer screens
- ► Arc furnaces
- Laser printers
- ► Air-conditioning systems
- power supply networks
 - ► Short-term flicker (Pst) and long-term flicker (Plt)

VOLTAGE UNBALANCE



Faults generated

Causes linked to disturbances due to equipment

Causes linked to electrical


power supply networks

- ► Current or voltage not phase-shifted by 120° and with different amplitudes
- ► Load absorbing power in an unbalanced way on the 3 phases
- Disconnection of one electrical power supply phase
- Disconnection of one electrical power supply phase
- Parameters to be measured | Level of unbalance, direct, inverse and homopolar voltage or current



HARMONICS AND INTERHARMONICS

The current consumed by the loads no longer has a pure sinusoidal waveform. The current distortion implies a voltage distortion that also depends on the impedance of the source.



Harmonics: sinusoidal waves whose frequencies are multiples of 50 Hz superimposed on the fundamental wave. Interharmonics: component of the signal superimposed on the fundamental wave (50 Hz) but which is not a multiple of the fundamental (e.g. 175 Hz).

Faults generated


Causes linked to disturbances due to equipment

Causes linked to electrical power supply networks

Parameters to be measured

- ► Functional synchronization problems, switching
- ► Untimely tripping of circuit-breakers
- ► Induced heating reducing the life span of rotating machines, capacitors, power transformers and neutral conductors
- ► EQUIPMENT containing power electronics: variable speed drives, uninterruptible power supplies, dimmers, welding units
- Propagation of harmonic pollution from customers supplied by the same electrical network
- ► Global THD
- ► Harmonics order by order in % and RMS value

FREQUENCY VARIATIONS



The average value of the fundamental frequency must be $50 \text{ Hz} \pm 1\%$ in normal operating conditions.

Faults generated Causes linked to disturbances due to equipment


Causes linked to electrical power supply networks

Parameters to be measured

Frequency fluctuations are observed on non-interconnected networks and networks connected to electrical generator sets.

- ► Process shutdown
- ► Autonomous source control fault
- After an overload on networks that are not interconnected or on an electrical generator set
- ► Frequency F(Hz)

VOLTAGE SURGES



Surges of a few per cent which do not cause the voltage to deviate from the template \pm 10 %.

Faults generated

Causes linked to disturbances due to equipment

Causes linked to electrical power supply networks

Parameters to be measured

period is usually monitored.

Contributes to flicker, malfunction of the control systems acting on the

phase angle, acceleration/deceleration torque of motors

The maximum number of voltage surges during an observation

- ► Damage to sensitive electronic equipment
- Operations: motor startup, activation of a capacitor bank, activation of an inductance, etc.
- ► Activation of load adjustment systems
- ► Variation of production by independent producers (wind turbines, solar panels, etc.)
- ▶ Voltage surges according to the IEC 61000-3-3 standard, difference between two stable states (voltage change less than or equal to 0.5 % for 1 second)
- The characteristics of voltage surges are: duration (time between two stable states), largest voltage variation in relation to previous stable state (Umax), difference between the two stable states (Ustat)

Standards

For electrical power distributors, it is crucial to deliver a quality product, which means sinusoidal, balanced three-phase voltage below a rated value at a frequency of 50 Hz. It also means remaining consistent with the bill delivered to the end-user. To help distributors and users to monitor and improve electrical network quality, several standards have been drawn up.

The **EN 50160** standard defines the main characteristics of the quality of the voltage supplied by the LV and MV public distribution network at the customer delivery point: frequency, amplitude of the waveform, symmetry of the three-phase voltages during a predefined observation period.

It indicates the limits or values of the voltage specifications that any customer has a right to expect.

The IEC 61000-4-30 standard, meanwhile, has been established to measure the various voltage quality parameters and obtain reliable, reproducible and comparable results whatever the measurement instrument used and whatever the environmental conditions. This standard defines the methods for measuring each parameter and how to interpret the results. It also stipulates the precautions necessary when installing measurement instruments on live circuits.







MAP Range

HV / MV / LV electrical power quality analyzers - Class A

PRODUCT ADVANTAGES

- with the EN 61000-4-30 standard, Class A
- DETECTION of the fault LOCATION DIRECTION (upstream/downstream) for products with current channels
- TRANSIENTS
 with a high, variable sampling frequency
- MEASUREMENT OF
 HARMONICS
 (up to 50th order) and
 INTERHARMONICS
 (up to 50th group)
- FLICKER
 MEASUREMENT:

 IfI, Pst, Plt
- of the data according to the EN 50160 standard





Communication port: local, modem, integrated Ethernet, multi-point



Status LED: phase order and template overrun



Communication couplers: local, modem, Ethernet

General specifications

The products in the **MAP** range, mounted on a platen or on the cabinet backplate, measure all the parameters of HV/MV/LV electrical networks: RMS voltage, frequency, THD, level of unbalance, positive/negative/zero sequence voltage, flicker, harmonics up to the 50th order, interharmonics up to the 50th group. For products with current channels: RMS current, THDI, active, reactive and apparent power, cos ϕ , power factor, power values of harmonics, energy values (calculated by the software).

The products in the **MAP** range record and, via the associated software, provide detailed, comprehensive and continuous analysis of the quality of the electricity supplied according to the applicable standards, particularly EN 50160: voltage variations (voltage dips, swells and outages), rapid variations (transient overvoltages), flicker or rapid voltage fluctuations...

Various communication modes are available for remote retrieval of the data and detailed analysis of all the parameters recorded. On some models, additional 20 mA analogue inputs can be used to:

- monitor physical parameters from a 20 mA transducer
- monitor statuses such as circuit-breaker contacts and protection relays via suitable couplers
- trigger waveform capture by a digital channel via a digital input/20 mA signal coupler
- · check the equipment transmitting binary signals



MAP 607

Single-phase analyzer — Class A

- 2 voltage channels: phase/neutral and phase/neutral-earth
- Plug & play: no driver required
- USB 2.0 communication port
- Configuration for voltage dips, overvoltages and transient disturbances
- Class A according to IEC 61000-4-30
- Measurement of all the power quality parameters according to the predefined standard (EN 50160, etc.)
- Direct indication on the product:
 Green LED: parameters OK
 Red LED: parameters outside profile

Management and analysis software

- Qual-SRT: configuration and real-time display
- Qual-view: analysis and reports



Inputs			
Voltage input (Phase-Neutral)	0-300 V RMS	Standard measurement (Class A)	1
Voltage input (Phase/Neutral-Earth)	0-300 V RMS, 700 Vpk	· /	1
Power supply	· · ·		
Power supply range		Power supply via voltage input	Yes
Internal back-up			Yes
Compliance with standards			
Sliding reference			Yes
IEC 61000-4-30, Class A	< 0.1%	Reference equipment	Yes
IEC 61000-4-7		Measurement of harmonics	Yes
IEC 61000-4-15		Flicker measurement	Yes
EN 50 160 (European Norm)		Calculated in the unit	Yes
PQDIF format			Option
Hardware			
Memory		Circular Flash Memory (NAND)	64 MB
Sampling rate			12.8 kHz (x 2)
Accuracy		Class A	< 0.1%
Resolution			16 bits
Input impedance — Input voltage			10 MΩ
Anti-aliasing filter			Yes
Bandwidth			3.5 kHz
PLL Synchronization			Yes
Communication			
USB port	2.0 (full-speed)	For PC connection, detected automatically Driver not required	Yes
Measurement specifications		· ·	
All power quality parameters are measured		Voltage (avg/min/max), Frequency, THD, Harmon-	Yes
and stored		ics (up to 50th order), Flicker (Lfl, Pst, Plt)	
Analysis of rapid disturbances		Dips/swells (RMS 1/2 cycle), transients	Yes
Waveform capture		Programmable pre-time and post-time	Max. duration 200 cycles
Mechanical specifications			
Housing	For 230 V socket	Humidity: 10% - 85% without condensation	
Dimensions (L x H x D)	120 x 65 x 65 mm		
Weight	0.3 kg	Safety: EN 61 010-1	
Operating temperature	-10°C +55°C	EMC: EN 58 081-1,2; EN 50 082-1,2	

	T () () I	R I	D I	Ε	R
--	-----	-----	-----	-----	-----	---	---

	Reference
Package includes: - MAP607 - mini USB cable - Qual-view and Qual-SRT software	MAP607-P
- carrying case	







MAP Range

Permanent analyzers - Three-phase

		Voltage	Voltage /	Current
Inputs	Specifications	MAP 610	MAP 620	MAP 640
Voltage	0-275/400 VRMS, 400/690 V (option)	3	3	3
HF voltage	0-275 VRMS (6 kV), high frequency (2 MHz)	-	-	3
Current	0-6 A RMS	-	4	4
General	0-20 mA analogue inputs	-	4	4
Network quality parameters			Y	
Voltage	Min, Max, average values	Х	Х	Х
Frequency		X	Х	Х
Unbalance	D. 40 : 80 2 6 11	X	Х	Х
Lfl, Pst and Plt flicker	Pst 10 min, Plt 2 h, Selectable storage range	X	Х	Х
Signalling voltages	< 3,000 Hz	Х	Х	X
THD-F	H . FOIL I	X	X	X
Individual harmonics	Up to 50th order	X	X	X
Interharmonics	Up to 50th group	X	X	X
Voltage surges	Number of times and variation (%)	X	X	X
Sliding reference	Complies with IEC 61000-4-30 Class A	Х	Х	Х
Other parameters	M:- M:	T	l v	v
Current harmonics	Min, Max and average values Up to 50th order	-	X	X
Power measurement	P/Q/S, PF/cosφ	-	χ	χ
Energy measurement in the software	active, reactive, apparent	-	χ	χ
Event-related	active, reactive, apparent		^	^
Dips / overvoltages / interruptions / outages	1/2-1 cycles RMS, Class A	Х	Х	Х
Calculation of event direction	Upstream/Downstream	^	χ	χ
Signature recording	12.8 kHz, half-period RMS curve	X	χ	χ
Pre-/post-triggering	Pre/post configurable, Pre+Post ≤15 s	X	X	χ
Waveform recording	Configurable up to 12.8 kHz	X	X	X
Pre-/post-triggering	Pre/post configurable, Pre+Post ≤ 20 cycles	610-300	X	X
HF transients, peak detection	2 MHz	610-300	X	X
Recording of waveforms and HF transients	22	-	-	X
Power supply				
Power supply input range	85-264 Vac / 110-375 Vdc, (47-63 Hz)	Х	Х	Х
Internal back-up		Х	Х	Х
Compliance with standards	•	•		
IEC 61000-4-30, Class A	< 0.1%, reference standard	X	Х	Х
IEC 61000-4-7	Measurement of harmonics	Х	Х	Х
IEC 61000-4-15	Flicker measurement	Х	Х	Х
EN 50 160	Calculated in the equipment	Х	Х	Х
Customized reports	Calculated in the equipment	Х	Х	Х
PQDIF format		Option	Option	Option
Hardware				
Memory	128 MB Flash memory (NAND)	Х	Х	Х
Sampling frequency		12.8 kHz	12.8 kHz	12.8 kHz / 2 MHz
Voltage accuracy		< 0.1 %	< 0.1 %	< 0.1 %
Resolution		16 bit	16 bit	16/10 bit
Standard bandwidth / HF		3.5 kHz / -	3.5 kHz / -	3.5 kHz / 1 MHz
Input impedance - voltage input		1 ΜΩ	1 ΜΩ	1 ΜΩ
Input impedance — current input		-	10 mΩ	10 mΩ
Anti-aliasing filter		Х	Х	Х
Communication				
RS-232	PC port	Х	Х	Х
RS-232	Modems, external couplers, etc.	Х	Х	Х
CL port	Current loop port	Х	Х	Х
Ethernet port (RJ-45)	Ethernet port	Option	Option	Option
Mechanical specifications		Tara est		
Dimensions (L x H x D) in mm			160 x 240 x 90	
Weight	1	1.3 kg	1.3 kg	1.7 kg
Operating temperature	1	-10°C / +50°C	-10°C / +50°C	-10°C / +50°C





Non-intrusive analyzers - Three-phase

	[Voltage	Voltage / Current
Inputs	Specifications	MAP 612-NI	MAP 620-NI
Voltage	275/400 VRMS, reference equipment (Class A)	3	3
Voltage range	400/690 V RMS	Option	Option
HF voltage	high frequency (2 MHz)	-	-
Current via external sensor	120 A, 1.2 kA, 1 kA flex RMS selectable	-	4*
Network quality parameters	120 rg 112 rag 1 rat nex mile solectable		
Voltage	Min, Max and average values	Х	X
Frequency	Tim, Trux und utcruge values	X	X
Unbalance		X	χ
Lfl, Pst and Plt flicker	Pst 10 min, Plt 2 h, Selectable storage range	X	X
Signalling voltages	< 3,000 Hz	X	X
THD-F	< 3,000 HZ	X	χ
Individual harmonics	II. to FO(L and a		
	Up to 50th order	Х Х	X
Interharmonics	Up to 50th group		X
Voltage surges	Number of times and variation (%)	Х	Х
Sliding reference	Complies with IEC 61000-4-30 Class A	Х	<u> </u>
Other parameters			
Current	Min, Max and average values	-	Х
Current harmonics	Up to 50th order	-	Х
Power measurement	P/Q/S, FP/cosφ	-	Х
Energy measurement in the software	active, reactive, apparent	-	Х
Event-related			
Dips / overvoltages / interruptions / outages	1/2-1 cycles RMS, Class A	Х	Х
Calculation of event direction	Upstream/Downstream	-	Х
Signature recording	12.8 kHz, half-period RMS curve	Х	Х
Pre-/post-triggering	Pre/post configurable, Pre+Post ≤15 s	Х	Х
Waveform recording	Configurable up to 12.8 kHz	-	Х
Pre-/post-triggering	Pre/post configurable, Pre+Post ≤20 cycles	_	Х
HF transients, peak detection	2 MHz	-	-
Recording of waveforms and HF transients		-	-
Power supply	·		
Power supply input range	85-264 Vac, (47-63 Hz) powered on phase 1 measurement	Х	l x
Separate power supply input	85-264 Vac / 110-375 Vdc, (47-63 Hz)	Option	Option
Internal back-up	03 201 140 7 110 373 140, (17 03 112)	Х	Х
Compliance with standards		Λ	
IEC 61000-4-30, Class A	< 0.1%, reference standard	Х	X
IEC 61000-4-70, Class A	Measurement of harmonics	X	X
IEC 61000-4-7	Flicker measurement	X	X
EN 50 160	Calculated in the equipment	X	χ
Customized reports	Calculated in the equipment	X	χ
	Calculated in the equipment		
PQDIF format	l l	Option	Option
Hardware	120 MD Flack (MAND)	v	l v
Memory	128 MB Flash memory (NAND)	X 12.0 LU-	X 12.0 LU-
Sampling frequency		12.8 kHz	12.8 kHz
Voltage accuracy		< 0.1 %	< 0.1 %
Resolution		16 bits	16 bits
Standard bandwidth / HF		3.5 kHz / -	3.5 kHz / -
Input impedance — voltage input		1 ΜΩ	1 ΜΩ
Input impedance — current input		-	ext. sensor
Anti-aliasing filter		Х	Х
Communication			
RS 232	PC port	Х	Х
RS 232	Modems, external couplers, etc.	Х	Х
CL Port	Current loop port	<u>-</u>	-
Ethernet port (RJ-45)	Ethernet port	Option	Option
Mechanical specifications			
Dimensions (L x H x D) in mm		160 x 240 x 60	160 x 240 x 90
IP65 casing and connections		-	-
Weight		1.3 kg	1.3 kg
Operating temperature		-10°C / +50°C	-10°C / +50°C
1	<u>.</u>		,

 $[\]ensuremath{^{*}}$ Accessory for external power supply for flex



MAP Range

Self-powered analyzer – Measurement in pole-mounted boxes



Output via leakproof connectors on the underside of the box



TO ORDER,
PLEASE CONTACT US

Environment

Operating temperature:

-10°C to + 50°C

Relative humidity:

10% - 85%, without condensation

Installation category:

Category III, $600\,\mathrm{V}$ ($300\,\mathrm{V}$ for the MAP607)

Pollution level: 2

Compliance with standards

Measurements:

- EN 61000-4-30: Voltage quality measurement method (Class A RMS values)
- EN 61000-4-7: General guide to harmonic and interharmonic measurements
- EN 61000-4-15: Test and measurement technique: flickermeter

Safety (Low Voltage Directive):

- EN 61010-1: Safety rules for electrical equipment for measurement, testing and laboratory use
- EN 60950: Safety of data processing equipment

Communication:

- Protocol compatible with the associated Qual-SRT, E.Qual-Premium and E.Qual-Premium Server software, TCP/IP encapsulation on internal Ethernet port (option)

Electromagnetic compatibility:

- EN 61326-1: Instructions concerning EMC for electrical measurement, control and laboratory equipment including:
- EN 61000-4-2: Electrostatic discharge Level 3 (Air 8 kV / Contact 4 kV)
- EN 61000-4-3: Immunity to radiated electrostatic fields Level 3 (10 V/m)
- EN 61000-4-4: Fast electrical transients Level 4 (2 kV)
- EN 61000-4-5: Immunity to voltage surges Level 4 (common mode 2 kV, differential mode 1 kV)
- EN 61000-4-6: Immunity to conducted disturbances Level 3 (3 Vrms)
- EN 61000-4-8: Level 4 (30 A/m)
- EN 61000-4-11: Level 0 (duration 0.5 period voltage dip and short interruption 100% U)
- EN 61000-4-12: Level 3 (common mode 2.5 kV / diff. mode 1.0 kV)
- CISPR 16-2-1, CISPR 16-2-3, EN55011 (EN5022 required by the generic standard EN 61326)

Mechanical specifications

Weight


- 1.3 kg (MAP 610, MAP612-NI, MAP 620 and MAP640)
- Mechanical shock test: EN60068-2-27: table 1: 30 g/18 m sec


Connection:

- 4 mm² cable for U and I
- 2.5 mm² cable for inputs/outputs



► Electrical connections





Dimensions









MAP Range


► Connection systems

Permanent analyzers MAP

	MAP 610	MAP 620	MAP 640	MAP Compact
		Screw-on connectors		
Voltage				Gurnerd Wolfage Prower 1 1 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Current	-	-		

Non-intrusive MAP

MAP 620-NI / Nix
1/4 turn connection systems
620-NI
0000
0 0 0 0
620-Nix
(independent power supply)
0000
0 0 0 0



Example: • order MAP640-E40 for a MAP640 Model + Without digital outputs + Ethernet port + 48 Vdc power supply
• order MAP610C046 for a MAP610 Model + With digital outputs + Without Ethernet port + 48 Vdc power supply + 690 VRMS voltage inputs




MAP Compact

Compact Power Quality Analyzer— Class A with monitoring of EN50160 template and calculation of energy values



- Measurement compliant with IEC 61000-4-30 Class A
- Integrated EN50160 report generation function
- Recording of voltage dips / swells / outages
- Waveform capture with programmable pre-time and post-time
- Measurement of power and energy values as primary quantities
- Communication interfaces

- Compact format for installation in existing cabinets
- Configuration and display software: Qual-SRTc, Qual-View
- Management and analysis software: E.Qual-Premium Server





Specifications


Inputs		Characteristics				
PH/N, PH/PH voltage input	3	0-364/0-630 VRMS	Impedance 1 MΩ			
Current input	3	0-6 A RMS	Impedance 10 mΩ			
CT and VT ratio	•	-	-			
Sampling and algorithmic cor	nformity					
Sampling	-	12.8 kHz / 16 bits	Anti-aliasing filter and PLL synchronization			
Bandwidth	-	3.5 kHz	-			
Network quality	-	IEC 61000-4-30 Class A	-			
Harmonics	-	IEC 61000-4-7	50th order			
Flicker	-	IEC 61000-4-15	-			
Voltage surges	-	IEC 61000-3-3	-			
Template monitoring	-	EN50160	-			
Parameters measured						
Voltage	•	-	EN 50160			
Frequency	•	-	EN 50160			
Unbalance	•	-	EN 50160			
Harmonics	•	-	EN 50160			
Flicker (Pst, Plt, Ifl)	•	-	EN 50160			
Current	•	-	10 mn			
Power	•	P/Q/S, FP, cosq	Selectable integration			
Energy	•	kWh, kVArh	Selectable integration			
Storage, communication and	display					
Mini-USB	•	-	-			
CL port	•	-	-			
RS232 port	•	-	-			
Ethernet port	Available as an option	-	-			
Storage capacity	Flash, circular	64 MB	-			
Display	Navigation keys	3 lines	U, I, events			
Power supply and power reso	erve					
Power supply	-	175 Vac to 255 Vac	-			
Internal power reserve	-	10 s	-			
Mechanical specifications						
Dimensions	-	155 x 165 x 68 mm	-			
Weight	-	0.9 kg	-			
Operating temperature	-	-10°C to +55°C	-			
		Integrated EN50160 reports				
Advantages		Display	W. (1V.)			
	Mea	surement of network quality and energy in kV	Vh / kVarh			
		Compact format				



MAP Software Range

Management and analysis software







Graphic display of all the available parameters



Configuration and manual or automatic retrieval of the data



Generation of reports

Description

Depending on the model, the range of software for MAP allows:

- configuration of the MAP
- creation of call sessions
- display of the electrical parameters (monitoring mode)
- retrieval of recorded data
- analysis of the disturbances and transients
- EN 50160 analysis
- a point-to-point or client/server architecture
- an automatic data retrieval engine
- multi-equipment analysis sessions
- external synchronization by server
- an event viewer module for standby control rooms
- report printing
- transmission of alarms by e-mail, SMS, etc.



Software for MAP 607

Qual-SRT and Qual-View

Qual-SRT and Qual-View are dedicated software modules for the MAP607 single-phase network analyzer.

Qual-SRT: configuration and real-time display module for "online" display of:


- the measurements on the MAP607's two channels
- the number of dips / swells / long interruptions / short interruptions / transients recorded
- the overall status of the last EN 50160 report
- the memory occupation rate
- the equipment date and time

Dynamic views are also available: trend curve (logger-type view) and bargraph of harmonics up to the 50th order. Thanks to the ultra-fast self-declaring USB 2.0 link, this module can also be used for almost instantaneous recovery of the data and deletion of the data from the equipment.


Qual-View: analysis and report generation module for MAP607-type data.

This provides a view of all the trend curves generated by the equipment and includes zoom and graphic display functions concerning the limits of the power quality profile for each parameter.


Event-related views such as event signatures, waveforms and time/date-stamped event log can also be obtained using dedicated tabs in the Qual-View software. It is possible to apply a power quality profile to the measurement campaign retrieved from the MAP607.




Qual-SRT: real-time display of the waveform in connection with a MAP607



Qual-View: graphic display of the measurement campaign retrieved (trends)



Qual-SRT: real-time display of harmonics bargraph



Qual-View: display of the waveform of a retrieved event (interruption)

Т	0	0	R	D	Е	R

Model	Reference
Configuration software	QUAL-SRT
Display software	QUAL-VIEW



MAP range

Single-phase network analyzer









MAP Software Range

Management and analysis software for the MAP range

E.Qual-Premium and E.Qual-Premium Server

The **E.Qual-Premium** software can be used to generate different views corresponding to the different parameters present in the measurement campaign recovered with:

- the views of the events
- the views of the transients
- the views of trend curves
- the views of the measurement campaign summaries
- the reports generated directly in MS Word® format and, in addition for the client / server version **E.Qual-Premium Server:**
- the multi-equipment graphic views
- the multi-equipment event logs
- the statistical views

The E.Qual-Premium and E.Qual-Premium Server software modules are compatible with all the products in the MAP range.

	E.Qual-Premium	E.Qual-Premium Server5	E.Qual-Premium Server
			THE
Architecture			
Point to point	•	•	•
Multi-equipment by successive targeting	•	•	•
Management of measurements in database	-	•	•
Multi-site / multi-equipment	-	•	•
Client / Server architecture	-	•	•
Number of devices managed	5	5	> 5
Data transfer			
Manual	•	•	•
Selective transfer	•	•	•
Automatic transfer	-	•	•
Communication log	-	•	•
Measurement display			
Real-time waveform and vectorial	•	•	•
Recorded curves	•	•	•
Curves with multi-equipment parameters	-	•	•
Global measurement campaign	-	•	•
Event display			
List of events	•	•	•
Waveform and fast RMS	•	•	•
Sorted views	-	•	•
Statistical view of events	-	•	•
Report generation			
Standard report covering one week	•	•	•
Report covering customizable period	-	•	•



Management and analysis software for the MAP range

ultilingual structure ulti-equipment point-to-point by successive targeting umber of devices managed icence for managing additional equipment easurement management in file mode easurement management in SQL Server database ulti-site / multi-equipment itent / Server and single-station Client / Server architecture cossibility of remote clients Lata transfer and type anual transfer utomatic transfer elective transfer between start date and end date transfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order transfer of frequencies transfer of summarized events transfer of waveforms transfer of EN50160 reports and customized profiles transfer of EN50160 reports and customized profiles transfer of transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I dividual harmonics up to 50th order argraph of U/I harmonics up to 50th order argraph inlimits of profile tatistical integration (X%) for each parameter	• • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	· · · · · · · · · · · · · · · · · · ·
ulti-equipment point-to-point by successive targeting umber of devices managed icence for managing additional equipment easurement management in file mode easurement management in SQL Server database ulti-site / multi-equipment in sql Server architecture cossibility of remote clients vata transfer and type anual transfer utomatic transfer elective transfer between start date and end date transfer of average, minimum and maximum values transfer of frequencies ransfer of summarized events transfer of summarized events transfer of waveforms transfer of waveforms transfer of EN50160 reports and customized profiles transfer display easurement time period coltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I addividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt storage intervals ax / min limits of profile	• 5 • • • • • • • • • • • • • • • • • •	· 5 · · · · · · · · · · · · · · · · · ·	· > 5
ulti-equipment point-to-point by successive targeting umber of devices managed icence for managing additional equipment easurement management in file mode easurement management in SQL Server database ulti-site / multi-equipment in sql Server architecture cossibility of remote clients vata transfer and type anual transfer utomatic transfer elective transfer between start date and end date transfer of average, minimum and maximum values transfer of frequencies ransfer of summarized events transfer of summarized events transfer of waveforms transfer of waveforms transfer of EN50160 reports and customized profiles transfer display easurement time period coltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I addividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt storage intervals ax / min limits of profile	5 • • • • • • • • • • • • •	•	> 5
umber of devices managed icence for managing additional equipment easurement management in file mode easurement management in file mode easurement management in SQL Server database ulti-site / multi-equipment itent / Server and single-station Client / Server architecture ossibility of remote clients Pata transfer and type anual transfer utomatic transfer elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of frequencies ransfer of frequencies ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles leal-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I dividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration If / YT ratios torage intervals ax / min limits of profile	•	•	•
icence for managing additional equipment easurement management in file mode easurement management in file mode easurement management in SQL Server database ulti-site / multi-equipment itent / Server and single-station Client / Server architecture ossibility of remote clients lata transfer and type anual transfer utomatic transfer elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of frequencies ransfer of summarized events ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of EN50160 reports and customized profiles leal-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I dividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt ionfiguration I / YT ratios lorage intervals ax / min limits of profile	•	•	•
easurement management in file mode easurement management in SQL Server database ulti-site / multi-equipment ient / Server and single-station Client / Server architecture ossibility of remote clients Pata transfer and type anual transfer utomatic transfer elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of summarized events ransfer of summarized events ransfer of waveforms ransfer of EN50160 reports and customized profiles teal-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I dividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / YT ratios torage intervals ax / min limits of profile	•	•	•
easurement management in SQL Server database ulti-site / multi-equipment ient / Server and single-station Client / Server architecture ossibility of remote clients Data transfer and type anual transfer utomatic transfer elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of summarized events ransfer of waveforms ransfer of waveforms ransfer of EN50160 reports and customized profiles deal-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I dividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / YT ratios torage intervals ax / min limits of profile	•	•	•
ulti-site / multi-equipment lient / Server and single-station Client / Server architecture lossibility of remote clients lata transfer and type lanual transfer utomatic transfer letective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of half-period RMS curve signatures ransfer of waveforms letel-time display leasurement time period lottage / current / power values / unbalance / frequency lip / swell / transient counter lacroscopic status of internal power quality report ly waveforms and Fresnel vector ly waveforms and Fresnel vector ly waveforms and Fresnel vector ly U / THD I lidividual harmonics up to 50th order largraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt lonfiguration I / YT ratios lorage intervals lax / min limits of profile	•	•	•
ient / Server and single-station Client / Server architecture cossibility of remote clients cossibility of remote clients chata transfer and type annual transfer cutomatic transfer cutomatic transfer clective transfer between start date and end date cransfer of average, minimum and maximum values cransfer of harmonics and interharmonics order by order cransfer of frequencies cransfer of summarized events cransfer of waveforms cransfer of EN50160 reports and customized profiles cleal-time display ceasurement time period coltage / current / power values / unbalance / frequency cip / swell / transient counter cacroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I coldividual harmonics up to 50th order cargraph of U/I harmonics up to 50th order clicker indicator: Lfl, Pst, Plt configuration I / YT ratios corage intervals ax / min limits of profile	•	•	•
ossibility of remote clients Pata transfer and type anual transfer utomatic transfer elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of summarized events ransfer of waveforms ransfer of EN50160 reports and customized profiles Real-time display reasurement time period poltage / current / power values / unbalance / frequency pip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I Individual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / VT ratios lorage intervals ax / min limits of profile	•	•	•
Patta transfer and type anual transfer utomatic transfer elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of summarized events ransfer of waveforms ransfer of EN50160 reports and customized profiles Real-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I individual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / VT ratios torage intervals ax / min limits of profile	•	•	•
anual transfer utomatic transfer utomatic transfer elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles deal-time display easurement time period obtage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I dividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / VT ratios torage intervals ax / min limits of profile	•	•	•
utomatic transfer elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles deal-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I Individual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt fonfiguration I / VT ratios torage intervals ax / min limits of profile	•	•	•
elective transfer between start date and end date ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles Real-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I adividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / VT ratios torage intervals ax / min limits of profile	•	•	•
ransfer of average, minimum and maximum values ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles Real-time display easurement time period pltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I advidual harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / YT ratios torage intervals ax / min limits of profile	•	•	•
ransfer of harmonics and interharmonics order by order ransfer of frequencies ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles teal-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I dividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / YT ratios torage intervals ax / min limits of profile	•	•	•
ransfer of frequencies ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles real-time display reasurement time period olitage / current / power values / unbalance / frequency ip / swell / transient counter racroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I real dividual harmonics up to 50th order rargraph of U/I harmonics up to 50th order	•	•	•
ransfer of summarized events ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles real-time display reasurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I real dividual harmonics up to 50th order rangraph of U/I harmonics up to 50th order ransfer of waveforms ransfer of RMS curve signatures	•	•	•
ransfer of half-period RMS curve signatures ransfer of waveforms ransfer of EN50160 reports and customized profiles real-time display reasurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I redividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt reformiguration T / YT ratios roage intervals ax / min limits of profile	•	•	•
ransfer of waveforms ransfer of ENSO160 reports and customized profiles Real-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I Individual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / VT ratios torage intervals ax / min limits of profile	•	•	•
ransfer of EN50160 reports and customized profiles Real-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I ndividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / VT ratios torage intervals ax / min limits of profile	•	•	
Real-time display easurement time period oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I Individual harmonics up to 50th order argraph of U/I harmonics up to 50th order alicker indicator: Lfl, Pst, Plt configuration I / VT ratios torage intervals ax / min limits of profile		-	•
easurement time period lottage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I adividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration I / YI ratios torage intervals ax / min limits of profile	•		
oltage / current / power values / unbalance / frequency ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I adividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration T / Y ratios torage intervals ax / min limits of profile	•		
ip / swell / transient counter acroscopic status of internal power quality report // waveforms and Fresnel vector HD U / THD I adividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration T / YT ratios torage intervals ax / min limits of profile		•	•
acroscopic status of internal power quality report /I waveforms and Fresnel vector HD U / THD I Individual harmonics up to 50th order Individual harmonics up to 50th order Indicator: Lfl, Pst, Plt Individual harmonics up to 50th order If / YT ratios It / YT ratios	•	•	•
// waveforms and Fresnel vector HD U / THD I Individual harmonics up to 50th order Individual harmonics up to 50th order Individual harmonics up to 50th order Indicator: Lfl, Pst, Plt Indicatorial harmonics If / YT ratios It is intervals In a waveforms and Fresnel vector Indicator in it is interval in it is	•	•	•
HD U / THD I Individual harmonics up to 50th order Individual harmonics up to 50th order Indicator: Lfl, Pst, Plt Indicatorial configuration If / YT ratios Intervals In a configuration In a configur	•	•	•
ndividual harmonics up to 50th order argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration T / YT ratios torage intervals ax / min limits of profile	•	•	•
argraph of U/I harmonics up to 50th order licker indicator: Lfl, Pst, Plt configuration T / YT ratios torage intervals ax / min limits of profile	•	•	•
icker indicator: Lfl, Pst, Plt configuration T / YT ratios torage intervals ax / min limits of profile	•	•	•
onfiguration T / VT ratios torage intervals ax / min limits of profile	•	•	•
T / VT ratios torage intervals ax / min limits of profile	•	•	•
torage intervals ax / min limits of profile			
ax / min limits of profile	•	•	•
	•	•	•
atistical integration (X%) for each parameter	•	•	•
	•	•	•
imit for dips / swells	•	•	•
re-time and post-time for RMS signature and waveform	•	•	•
imit for transients	•	•	•
re-time and post-time for transients	•	•	•
larm events	•	•	•
MS alarms	•	•	•
nit, scale factor and offset for general inputs	•	•	•
riggering on digital channels	option	option	option
leasurement campaign analysis			
raph of average values	•	•	•
uperimposing of half-period min / max envelope	•	•	•
uperimposing of min/max limit reached	•	•	•
uperimposing of power quality profile min/max limit		•	•
ulti-curve / multi-parameter graph	•	•	•
oom in / out	•	•	•
nchronized zoom on several curves			•
nchronized displacement of several curves	•	•	

		E.Qual-	E.Qual-
	E.Qual-	Premium	Premium
	Premium	Server5	Server
Analysis of events			l.
Filtered lists of summarized events	•	•	•
Detailed view of event parameters	•	•	•
Fast RMS envelope event view	•	•	•
Graphic overlay of U/I envelope	•	•	•
Fast RMS envelope view displacement	•	•	•
Event waveform view	•	•	•
Superimposing of U/I waveform	•	•	•
Zoom in / out	•	•	•
Waveform view displacement	•	•	•
Event	•	•	•
Functions on the views			
Graphic copy in clipboard	•	•	•
Graphic recording on hard disk	•	•	•
Configuration of graph axis scales	•	•	•
Graphic printing configuration	•	•	•
Graphic printing	•	•	•
Report generation			
Standard report generation	•	•	•
Customized report generation	•	•	•
One-week report generation	•	•	•
Customizable-period report generation	option	•	•
Multi-site / multi-equipment mode			ı
Regional multi-base data source	-	•	•
Possibility of inserting retrieved file in base	-	•	•
Multi-parameter / multi-equipment graphics	-	•	•
Summarized multi-equipment event impact view	-	•	•
Multi-equipment list of summarized events	-	•	•
Interactive viewer: list / summarized view / detailed view	-	•	•
Multi-equipment event list sorting	-	•	•
Filtered multi-equipment summarized event list	-	•	•
Advanced event list filter	-	•	•
Event CSV export	-	•	•
Multi-equipment communication log ITIC statistical viewer		•	•
SEMI47 statistical viewer		•	•
UNIPEDE table statistical viewer	-		•
Measurement campaign Excel export	-	•	•
Measurement campaign PQDIF export		option	option
Overview of energy values in selectable interval		•	•
CSV export of energy values	-	•	•
Administration of automatic remote retrieval			
Frequency of automatic remote retrieval		•	•
Frequency: never/immediate/10 min / hour / day / week	_	•	•
Normal transfer / all data / with harmonics		•	•
Possibility of automatic deletion after retrieval		•	•
Automatic remote retrieval start date / time		•	•
Communication for remote retrieval for each device	_	•	•
Communication for remote retrieval for each device			





MAP Software Range

Management and analysis software for the MAP range

► General specifications

Parameters according to EN 50160

- Network frequency
- Power supply voltage
- Slow and rapid voltage variations
- Short and long outages
- Voltage dips and asymmetries
- Harmonic and interharmonic voltages
- 50 Hz transient overvoltages

Flicker

■ Flicker measurement according to EN 61000-4-15: short-term flicker (Pst), long-term flicker (Plt)

Voltage and current

- TRMS value and average value
- Peak value and crest factor

Power / Energy values

- Active power produced and consumed
- Inductive or capacitive reactive power
- Apparent power, power factor and Cos φ
- Active energy produced and consumed
- Inductive or capacitive reactive energy
- Apparent energy

Harmonic breakdown up to 50th order

- Harmonics: current, voltage, power in relation to the fundamental and in absolute terms
- Phase shift of each harmonic order
- Global THD global and order by order
- Recognition of the direction of each harmonic order

Analysis of three-phase system unbalance


- Measurement of a system's symmetry: positive, negative, zero sequence components
- Phase shift
- Vectorial representation of voltage and current

Analysis on networks


- Recording of "short-circuit" events (faultograph function)
- Location of the fault, duration of the phenomenon
- Analysis of the network impedance
- Analysis of remote control signals: definition and verification of the frame
- Verification of equipment operation (capacitors, filters, circuit-breakers)

Dip / overvoltage / interruption / outage events

After retrieving the data recorded by the MAP network analyzers, the dip/overvoltage/interruption/outage events captured when outside the programmed profile can be displayed in different views available in the E.Qual-Premium software. The zoom function can be used on the views.



View of the signature curve of a voltage dip, obtained using the fast RMS values refreshed every half-period. The pre-time and post-time for recording are those programmed in the MAP network analyzer.




View of the signature curve of a voltage dip superimposed with the waveforms of the real signals on the three phases. The waveforms are displayed with a high resolution matching the sampling rate, i.e. 12,800 Hz. The event-related view is given directly in the primary quantity, taking into account the CT and VT transformation ratios of the substation where the measurements were taken.



Management and analysis software for the MAP range

Subcyclic transients


With the fast transient capture mode, transient events can be viewed with a resolution of 12.8 KHz or 2 MHz, depending on the MAP model. The detection templates are in positive and/or negative dV/dT.




Three-phase view of a fast transient affecting the network's phases.

Trend curves of the parameters recorded by the MAPs

The E.Qual-Premium software can manage a large number of trend curves. After retrieval the curves containing all the parameters covered by the EN 50160 standard, as well as the power values, power factors and Cos φ can be viewed and zoomed on.



View of the trend curves of the three-phase voltages during a MAP measurement campaign, as analysed by the graphic module of the E.Qual-Premium software.



Stacked view of two different graphs from the same measurement campaign. The E.Qual-Premium software allows you to stack as many curves as you wish.

Summary of the measurement campaign

SITE 1 (0508	011091)		MAP640		Dep 000000030003	0096	
Long-time data					Fepale		
Long-time data	Destro		for .		Passed	- 21	_
Votage RMS merman, U1 U4		09 10 44 00 AM	9/18/2009 1:34:0		Faled	-	
Total harmonic detection, UT-627		5 10 48 00 AM	5/18/2005 1 SAD		-	_	
Power Impulency	\$/27/20	09-3-03:50 AM	9/16/2009 1:36:1	QPM -	tion	20	
Distance 1/4//0	7/25/20	09 9 24:00 PM	5/18/2008 1 34 D	Q PM	- Control of the Cont	-	
Rober Pet		9 10.44.00 AM	9/16/2009 1/34:0				
Roker Pt		09 11 00 00 AM	5/18/2000 1 00 0				
Current RMS/Introfess. 11-14	2/19/20	05 10:44:00 AM	5/15/2005 1:34:3	GPM .			
Total hamonic distotion, IT-14	7/25/20	05 9:24:00 PW	9/16/2009 1:34 0	OFM.	Defigration		
Power Pf /cos phi	4/3/200	524500 AM	5/15/2009 1:35 0	GPM -	Name of soldings	20 30 44	_
hierias	4/13/20	06 6 45 00 PHE	9:15/2009 1:35:0	C'Pto	Gran.	EN SOVED LY	
Individual Namorous, UT-623	8/21/20	09 6 Z3 58 AW	5/18/2009 1:23 F	B PM	P7 (1) (M	200 200 200 1	
					CTINE	40 40 40 1	
					Udiff-Sag-(1)	10	
					USE-Seg (1)		
Firet.				_	Udf-Tenser (1)	50	
Everts with data		Everts effect	deta		USF- Transact (1)	40	
Teres	- 81	Non-report op	bessed	- 28	Foce	No.	
Say	33	Name report for	alled	1		No.	
		Sens runder o	rvent	- 1	Victoria de promiti.		
		Current configu	ration	10	Storg reference	No.	
		Unit clock sync	fworand	1	file codg	39/66	
		Date framework	on exceeded	10	Fesients	50 Hz	

View of the summary of the measurement campaign with the time periods present for each type of parameter.

Power Quality report view



View of preformatted or customized reports generated directly in MS Word® format. It is possible to create new report models which will then be added to the existing report model library.






MAP Software Range


Management and analysis software for the MAP range

E.Qual-Premium Server

The client/server version of the E.Qual-Premium Server software provides a multi-equipment, multi-parameter view of the measurements recovered by the automatic remote retrieval engine. It is then possible to put together totally customized views by "dragging and dropping" the parameters of different equipment items into the display area. Summarized and statistical views are also available.




Multi-equipment view with the client/server version of E.Qual-Premium. The parameters featuring in the view are chosen in the equipment / parameters / phases tree structure located on the left-hand side of the analysis window.




Multi-equipment log view of the dip / overvoltage / interruption / outage events. A summarized view shows the occurrence times of all the events recovered by the automatic remote retrieval engine. When you select an event in the list, the same event is automatically highlighted in the summarized view. You can open the RMS / waveform signature view by double-clicking on the event.

Statistical views of the impacts of dips / overvoltages / interruptions and outages compared with standardized templates such as the ITI profile, SEMI 47 and UNIPEDE table.



Statistical view of the dip / overvoltage / interruption / outage events compared with the ITI template




Statistical view of the dip / overvoltage / interruption / outage events compared with the SEMI 47 template.




Management and analysis software for the MAP range


E.Qual-Premium Server architecture


The E.Qual-Premium Server architecture is ideal for applications where you want to analyse the energy quality measurements gathered from several points in the electrical network and compile data supplied by different models in the MAP range. Thanks to its automatic remote retrieval engine, the E.Qual-Premium Server software is capable of transferring the data from the different network analyzers and integrating them into the system's SQL-server® base. The multi-equipment analysis module can then use the measurements stored in the database to generate composite views and statistics grouping information from several measurement points.



Components of an E.Qual-Premium Server with the network analyzers, the communication links, the database and the analysis and graphic display modules.











Audit and Troubleshooting Department

Engineers ready to listen and support any approach for electrical network optimization.







Enerdis uses Chauvin Arnoux® and Metrix® instruments for its troubleshooting activities



Experts carry out a totally customized study

Description

The specialized engineers comprising the **ENERDIS TROUBLESHOOTING DEPARTMENT** propose electrical network auditing services. The goal is to help you identify the main features of your industrial, tertiary and infrastructure networks.

Analysis of the parameters liable to cause malfunctions or excessive loads on the installations

Recommendation of solutions to meet the energy quality requirements.



Power supply faults and deterioration of electrical power supply quality cause disturbances whose cost is a major concern for industrial companies. Prevention is the best strategy for dealing with harmonic distortion, outages, voltage variations and transient phenomena.

Consequences of harmonic currents on the network

Often underestimated, harmonic currents cause problems at the level of both the distribution system and the installation:

- overheating of the neutral
- overheating of the transformers
- untimely tripping of protective devices
- overloading of capacitors
- skin effect in the conductors

The Enerdis Audit and Troubleshooting Department helps you to gain a better understanding of your electrical network and supports you in your search for suitable solutions.

Power quality

- Measurement of the energy quality parameters and compliance with the levels required by the EN 50160 standard
- Evaluation of the parameters outside the template and analysis of the danger for equipment and loads downstreams
- Evaluation of the interconnection parameters over several integration periods for measurement periods of up to one week


Study of the need for Power Factor Correction

- Evaluation of the power factor (cos φ) with activation of different types of loads
- Study of the need for Power Factor Correction to avoid penalties during the period of reference
- Recommendations for capacitor bank sizing: type of fixed/ regulated compensation, standard type of reinforcement, H or SAH



Study of harmonic pollution

- Measurement of harmonic pollution and evaluation at different points in the electrical distribution system
- Correlation with the activation of loads causing disturbances
- Global survey of harmonic pollution over a cycle representative of the site's load profile
- Recommendation of filtering solutions



Study of load profile

- Global energy survey of the site with study of the power components over a significant load period
- Evaluation of the load on the site's MV/LV transformers and possible overloading
- Evaluation of the load profile observed and the threshold effects on the tariff contract

Study of common-mode components

- Measurement of the common-mode currents liable to cause untimely tripping of CBs
- Measurement of the common-mode voltages liable to cause malfunctioning of sensitive downstream loads

Customized audits

In the context of the TROUBLESHOOTING activity, a made-tomeasure audit can be performed. Our experts carry out a customized survey of the different technical points stipulated in your specifications.


Work method: keeping as close as possible to the statement of requirements

- Contact to assess the precise requirements in a partnership between the customer and ENERDIS
- Drafting of a customized technical and sales offer
- Definition of a work schedule and the work method proposed
- Troubleshooting inspection by experienced staff with all the necessary electrical authorizations needed for on-site measurement work
- Instrumentation of the measurement points defined in the troubleshooting work method and recording of relevant measurements
- Generation of a troubleshooting report with recommendations









ENERDIS is the company specialized in fixed equipment for measurement, testing, metering and supervision of electrical networks, as well as energy-control solutions for all utilities.

The company joined the CHAUVIN ARNOUX Group in 1998, benefiting from the global R&D teams integrated production facilities to offer comprehensive expertise covering everything from electrical measurement through to energy performance.

Its offering is based around four major fields:

- **Network supervision:** quality analyzers, measurement transducers, tariff meters, etc.
- Energy management systems: submeters, power monitors, current transformers, environmental measurement sensors, energy information systems, etc.
- **Automation relays:** instantaneous relays, timedelay relays, function relays and sockets.
- Tailored services and solutions: tailored diagnostics, recommendations, training and development.

FRANCE Enerdis

16, rue Georges Besse - Silic 44 92182 ANTONY Cedex Tél: +33 1 75 60 10 30 Fax: +33 1 46 66 62 54 info@enerdis.fr www.enerdis.fr INTERNATIONAL Enerdis

16, rue Georges Besse - Silic 44 92182 ANTONY Cedex FRANCE Tél: +33 1 75 60 10 30 Fax: +33 1 46 66 62 54 export@enerdis.fr www.enerdis.com

